LED Header Panels

Window Displays
Wall Displays

LED Header Panel / Pocket

Why not add a LED Header Panel?

LED Header Panel / Pocket

Header Panels come in 4x Versions
Header Panels can be used on Suspended Window Displays
Header Panels can be used on Wall Displays

Header Panels create a 'Stunning Effect'

LED Header Panels
Window Displays
Wall Displays

LED Header Panel / Pocket

Can be used on Wall LED Displays + LED Window Displays
Header LED Panel - Designed to be used with the 3x listed LED Panels / Pockets

Simply add to your current display, then, add 2x insert messages (one on either side)





Header1 - Is designed for the below LED Panels (Underneath)





Supplied in 2x colours - Black Frames + Silver Frames

LED Header Panels
Window Displays
Wall Displays

LED Header Panel / Pocket

Can be used on Wall LED Displays + LED Window Displays
Header LED Panel - Designed to be used with the 3x listed LED Panels / Pockets

Simply add to your current display, then, add 2x insert messages (one on either side)



(Actual) = 626mm x 166mm
(Visible) = 612mm x 152mm



(Actual) = 626mm x 166mm
(Visible) = 612mm x 152mm

Header2 - Is designed for the below LED Panels (Underneath)



Supplied in 2x colours - Black Frames + Silver Frames

LED Header Panels
Window Displays
Wall Displays

LED Header Panel / Pocket

Can be used on Wall LED Displays + LED Window Displays
Header LED Panel - Designed to be used with the 3x listed LED Panels / Pockets

Simply add to your current display, then, add 2x insert messages (one on either side)



(Actual) = 594mm x 166mm
(Visible) = 580mm x 152mm

Header3 - Is designed for the below LED Panels (Underneath)



Supplied in 2x colours - Black Frames + Silver Frames

LED Header Panels
Window Displays
Wall Displays

Operation





Cable Fitting

Insert your 2x Cables between the 4x holes
Holes also have stand-offs to grip the cable

Rod Fittings

Insert your 2x Rods between the 4x holes
Holes also have stand-offs to grip the Rods

Changing the Posters

The Majority of clients only do this once as the 'Header' Panel is normally used for their Company Logo
To change the poster
First turn-off the power supply!
Insert you poster from the top section of the acrylic
If you have a Wall version you only need to do this once, as its only one-sided
If you have a window fitting, add both posters at the same time i.e. back-to-back
Once inserted correctly
Now you can turn the power supply back on!

Recommend Paper

120gsm Paper = Search for = PAPER
135gsm Paper = Search for = PAPER135

Recommend Film

125gsm Film = Search for = FILM-125gsm
160gsm Paper = Search for = FILM-160gsm